

BLP 103 ET

Pos	Code	Description
1	4162.759	OUTLET CONE
2	4160.759	OUTLET GRID
3	4162.758	COMBUSTION CHAMBER
4	4162.756	COVER
5	4162.934	PLASTIC HANDLE
6	4160.959	FAN
7	4160.047	ELECTRIC MOTOR
8	4160.758	INLET GRID
9	4161.012	ELECTRIC MOTOR BRACKET
10	4162.909	AIR PROBE COVER
11	4162.910	AIR PROBE
12	4162.816	AIR FLAP
13	4106.202	AIR PROBE BRACKET
14	4160.237	IGNITION ELECTRICAL FOLDER
15	4160.770	GAS NOZZLE
16	4160.768	SUPPORT GAS NOZZLE
17	4160.048	GAS INLET NOZZLE
18	4161.501	REDUCTION NIPPLES
19	4160.964	REDUCTION NIPPLES
20	4160.963	ELECTROVALVE
21	4161.095	REDUCTION NIPPLES
22	4160.962	REDUCTION NIPPLES
23	4162.772	COPPER TUBE
24	4160.967	ELBOW
25	4160.646	GROMMET
26	4161.854	BLOCK FOR NOZZLE
27	4162.467	COMPLETE PLUG-IN
28	4161.400	CONNECTION SOCKET
29	4160.647	ANGULAR FIX CASE
30	4160.539	POWER CORD
31	4150.528	STRAIN RELIEF
32	4162.777	FRAME
33	4110.129	WHEEL HUB
34	4110.162	WASHER
35	4110.084	WHEEL
36	4162.779	WHEEL AXLE
37	4160.637	SWITCH
38	4160.430	RESET SWITCH
39	4106.245	LED
40	4162.765	BASE
41	4106.246	ELECTRONIC PC BOARD
43	4162.760	BURNER SUPPORT
44	4162.771	GAS BURNER
45	4106.218	BURNER PLATE
46	4106.276	CAPACITOR