

BLP 53 ET

Pos	Code	Description
1	4100.814	OUTLET GRID
2	4162.731	COMBUSTION CHAMBER
3	4162.728	COVER
4	4162.934	PLASTIC HANDLE
5	4160.691	FAN
6	4160.046	ELECTRIC MOTOR
7	4160.739	INLET GRID
8	4162.733	ELECTRIC MOTOR BRACKET
9	4162.910	AIR PROBE
10	4162.909	COVER AIR PROBE
11	4106.047	AIR PROBE BRACKET
12	4160.237	IGNITION ELECTRICAL FOLDER
13	4162.869	PLATE BURNER
14	4160.646	GROMMET
15	4160.646	GROMMET
16	4161.854	BLOCK FOR NOZZLE
17	4160.020	ELECTROVALVE CABLE
18	4160.048	GAS INLET NOZZLE
19	4160.283	WASHER
20	4160.964	NIPPLES REDUCER
21	4160.963	ELECTROVALVE
22	4161.095	NIPPLES
23	4160.962	REDUCTION NIPPLES
24	4162.724	COPPER TUBE
25	4160.766	GAS NOZZLE
26	4160.967	ELBOW
27	4162.467	COMPLETE PLUG-IN
28	4161.400	CONNEXION SOCKET
29	4160.647	ANGULAR FIX CASE
30	4162.853	LOWER PLASTIC BASE
31	4031.627	CAPACITOR 3 μ F
32	4160.539	POWER CORD
33	4160.635	KEEPER WIRE
35	4106.246	ELECTRONIC PC BOARD
36	4162.854	UPPER PLASTIC BASE
37	4160.769	NECK PLATE
38	4160.430	RESET SWITCH
39	4106.245	LED
40	4160.637	SWITCH
41	4160.467	GAS BURNER