

B 35 CED

Pos	Code	Description
1	4110.130	Handle
2	4110.121	Upper Shell
3	4109.590	Screw/Lockwasher, 1/2"
4	4110.115	Combustion Chamber
5	4100.671	Heat Shield
6	4160.602	Screw, #10-16 x 3/4"
7	4100.658	Photocell Bracket
8	4103.529	Screw, #6-32 x 3/8"
9	4110.564	Photocell Assembly
10	4110.563	Power Cord
12	4105.287	Power Line RFI Filter
13	4101.151	Bushing
14	4150.528	Strain Relief Bushing
15	4100.662	Fan
16	4150.553	Rubber Bumper
17	4110.187	Motor Bracket
19	4103.685	Fan Guard
20	4108.486	Hex locknut
21	4101.152	Bushing (wires)
22	4110.124	Screw/Lockwasher, 1/2"
23	4110.535	Lower Shell
24	4104.170	Clip Nut
25	4110.133	Screw, #10-32 x 3/4"
26	4104.147	Rubber Airline
27	4109.567	Fuel Line
28	4110.195	Wire Assembly (red)
29	4100.541	Rubber Bushing
30	4110.135	Fuel Filter Assembly
31	4110.609	Electronic Ignitor
32	4108.510	Screw, #10-16 x 3/4"
33	4106.110	Terminal Board
34	4110.571	Rivet
35	4104.196	Flame-Out Control
36	4103.891	Fuel Tank Cap
37	4110.136	Fuel Tank
38	4104.175	Side Cover
39	4110.134	Nut, #10-32
40	4109.592	Hex Nut
41	4101.151	Bushing
42	4110.075	Vinyl Foam Gasket
43	4160.613	Lock Washer, #10
44	4110.165	Wire Assembly (black)
45	4106.179	ON/OFF Switch
46	4104.336	Switch Cover
11-1	4110.092	Bracket
11-2	4109.526	Spark Plug

Pos	Code	Description
11-3	4100.664	Nozzle Adapter
11-4	4109.518	Nut, 14mm
11-5	4100.648	Nozzle
18-1	4110.042	Motor (230V/50Hz)
18-2	4101.532	Pump Body
18-3	4108.635	Insert
18-4	4103.441	Rotor
18-5	4109.724	End Pump Cover
18-6	4109.716	Lint Filter
18-7	4109.690	Intake Filter
18-8	4109.674	End Cover
18-9	4108.528	Screw, #10-32 x 1"
18-10	4108.379	Steel Ball (1/4" Dia.)
18-11	4102.141	Pressure Relief Spring
18-12	4102.133	Adjusting Screw
18-13	4102.125	Plug
18-14	4109.708	Output Filter
18-15	4108.536	Screw, #10-32 x 1 1/8"
18-16	4100.661	Elbow, 90° (Barb Fitting)
18-17	4101.666	Blade
18-18	4108.590	Screw, #10-32 x 3/4"
not shown	4105.292	Filler Neck Screen
not shown	4100.426	Room Thermostat TH 2
not shown	4109.427	Pressure Gauge