

BV 77

Pos	Code	Description
1	4032.840	Chimney
2	S/R	Upper Body
3	4032.815	Motor 2P.150W 230V/50
4	4032.835	Motor Support
5	4032.545	Air Regulation Flap
6	4032.808	Air Deflector
7	4032.814	Fan Diam.250Mm-25Å°
8	4032.836	Grill
9	4032.811	Handle
10	4032.845	Fuel Level Probe
11	4032.813	Drain Plug
12	4032.828	Fuel Tank Black
13	4111.480	Wheel Plug Black
14	4111.072	Wheel Holder Diam. 20
15	4032.094	Wheel Black Diam.250
16	4032.809	Wheel Axle Black
17	S/R	Lower Body
18	4032.790	Combustion Chamber
19	4032.838	Outlet Air Cone
20	4031.536	Nozzle 0,40 Gph 80Å°S
21	4032.786	Nozzle Support
22	4032.574	Burner Flange
23	4031.540	Electrode
24	4161.434	Screw Tcc 4,2X9,5
25	4032.406	Photocell Support
26	4032.407	Nut M14X6
27	4161.140	Connection 90Å° M.M. 1/8"
28	4032.818	Photocell Fd11 Brahma
29	4111.153	Power Cord 3 Mt.
30	4111.038	Cable Fastener
31	4032.850	Fuse 2,5A 6,3X32Mm
32	4100.667	Switch 10 A
33	4160.647	Angle Fix Box
34	4162.467	Switch Cover
35	4032.823	Front Control Panel
36	4032.825	Brahma Equipment Tgr1
37	4032.824	Control Box Base
38	4160.639	Pop Rivet With Termin 4 Way
39	4032.787	Minirelay
40	4032.788	Minirelay Adapter
41	4032.816	Capacitor 6,3Mf
42	4032.789	Pump Danfoss
43	4161.501	Connection Straight 1/8" M.F.
44	4032.906	Rubber Tube M1/4
45	4032.857	Fuel Pipe Tank-Filter
46	4100.630	Fuel Filter

Pos	Code	Description
47	4032.830	Rubber Tube For Fuel Suction
48	4032.829	Rubber Tube
49	4032.858	Fuel Pipe Pump-Tank
50	4032.884	Fan Thermostat
51	4032.883	Limit Thermostat
52	4032.854	Oil Supply Pipe L=600
53	4032.885	Ht Cable
not shown	4150.105	Room Thermostat Th 5
not shown	4109.435	Pressure Gauge
not shown	4032.950	Hose Connection Kit
not shown	4032.951	Air Hose Å305 Mm, 3 M